


Serial Communication Protocol

PRELIMINARY



PLATINUM™  Series



 **NEWPORT®**
www.newportUS.com/manuals

Additional products from






Counters	Rate Meters
Frequency Meters	Timers
PID Controllers	Totalizers
Clock/Timers	Strain Gauge
Printers	Meters
Process Meters	Voltmeters
On/Off	Multimeters
Controllers	Soldering Iron
Recorders	Testers
Relative	pH pens
Humidity	pH Controllers
Transmitters	pH Electrodes
Thermocouples	RTDs
Thermistors	Thermowells
Wire	Flow Sensors
Wireless	

For Immediate Assistance
In the U.S.A. and Canada: 1-800-NEWPORT®
In Mexico: (95) 800-NEWPORTSM
Or call your local NEWPORT Office.

The information contained in this document is believed to be correct but NEWPORT Electronics, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, patient connected applications.

TRADEMARK NOTICE: ,  NEWPORT, NEWPORT®, and newportUS.com are trademarks of NEWPORT Electronics, Inc.

 This device is marked with the international caution symbol. It is important to read the Setup Guide before installing or commissioning this device as it contains important information relating to safety and EMC.

Newport Electronics, Inc.
2229 South Yale Street
Santa Ana, CA 92704

www.newportUS.com
info@newportUS.com

Table of Contents

1	Introduction.....	4
1.1	Purpose.....	4
1.2	Definition of Terms and Acronyms	4
1.3	Applicable Documents.....	5
2	Hardware	6
2.1	Communications Interfaces.....	6
2.1.1	RS-232	6
2.1.2	RS-485	6
2.1.3	USB Virtual Comm	6
2.1.4	Ethernet.....	6
3	Protocol Description	7
3.1	Protocol.....	7
3.2	Command Structure	7
3.3	Response Format	7
3.4	Error Messages	7
4	Platinum Series Messages.....	8
4.1	Input Configuration	8
4.2	Filter Constant	11
4.3	Current Reading	11
4.4	Peak Reading.....	12
4.5	Valley Reading.....	12
4.6	TC Calibration Type.....	12
4.7	TC Calibration Single Point	13
4.8	TC Calibration Double Point Low	13
4.9	TC Calibration Double Point High	13
4.10	Process Reading 1 (Low).....	13
4.11	Process Range Input 1 (Low)	14
4.12	Process Range Reading 2 (High)	15
4.13	Process Range Input 2 (High).....	15
4.14	Display Configuration	15
4.15	Excitation Voltage	16
4.16	Safety Configuration	17
4.17	Loop Break Configuration	18
4.18	Set Point Low Limit	18
4.19	Set Point High Limit	18
4.20	Serial Communication Address.....	19
4.21	USB Communication Address.....	19
4.22	Ethernet Communication Address.....	19
4.23	Serial Communication Config	19
4.24	Serial Data Mode Config	21
4.25	Serial Modbus Mode.....	21
4.26	Serial Data Format.....	22
4.27	Serial Communications Parameters	23
4.28	USB Communications Configuration.....	24

4.29	USB Data Mode Configuration	25
4.30	USB Modbus Mode.....	25
4.31	USB Data Format.....	25
4.32	Ethernet Communications Configuration.....	26
4.33	Ethernet Data Mode Configuration.....	26
4.34	Ethernet Data Format	26
4.35	Ethernet Modbus Mode.....	26
4.36	Setpoint 1.....	27
4.37	Remote Setpoint Configuration.....	27
4.38	Setpoint 2.....	28
4.39	Remote Process Range Setpoint Min	28
4.40	Remote Process Range Setpoint Max.....	29
4.41	Remote Process Range Input Max	29
4.42	Remote Process Range Input Min.....	29
4.43	PID Configuration.....	30
4.44	PID Low Clamping Limit	30
4.45	PID High Clamping Limit.....	31
4.46	PID P Parameter	31
4.47	PID I Parameter.....	31
4.48	PID D Parameter	31
4.49	Output Mode	32
4.50	Output Type	32
4.51	Output ON/OFF Configuration.....	33
4.52	Output Alarm Configuration	33
4.53	Hi Value.....	35
4.54	Low Value	35
4.55	On Delay.....	36
4.56	Off Delay	36
4.57	HiHi Mode.....	36
4.58	HiHi Offset.....	37
4.59	Output Retransmission Reading 1	37
4.60	Output Retransmission Output 1	37
4.61	Output Retransmission Reading 2.....	37
4.62	Output Retransmission Output 2	38
4.63	Output Cycle Time/Pulse Width.....	38
4.64	Output Range.....	38
4.65	Time Format.....	39
4.66	Multi Ramp/Soak Configuration	39
4.67	Multi Ramp/Soak Profile Configuration	39
4.68	Multi Ramp/Soak Segment Event Configuration.....	40
4.69	Multi Ramp/Soak Profile Segment Ramp Time.....	40
4.70	Multi Ramp/Soak Profile Segment Soak Process Value	40
4.71	Multi Ramp/Soak Profile Segment Soak Time	41
4.72	Start Calibration	Error! Bookmark not defined.
4.73	Manufacturing Ice Point.....	Error! Bookmark not defined.
4.74	TC Calibration Positive Scale Value.....	Error! Bookmark not defined.
4.75	TC Calibration Negative Scale Value	Error! Bookmark not defined.

4.76	TC Calibration Offset Value	Error! Bookmark not defined.
4.77	RTD Calibration Scale Value.....	Error! Bookmark not defined.
4.78	RTD Calibration Offset Value.....	Error! Bookmark not defined.
4.79	Thermistor Calibration Scale Value	Error! Bookmark not defined.
4.80	Thermistor Calibration Scale Value 2	Error! Bookmark not defined.
4.81	Thermistor Calibration Offset Value	Error! Bookmark not defined.
4.82	Process Calibration Positive Scale Value.....	Error! Bookmark not defined.
4.83	Process Calibration Negative Scale Value	Error! Bookmark not defined.
4.84	Process Calibration Offset Value	Error! Bookmark not defined.
4.85	INIT Password.....	41
4.86	Program Password.....	41
4.87	Version Number.....	42
4.88	Version Upgrade.....	42
4.89	Bootloader Version	43
4.90	Set Factory Defaults.....	43

1 Introduction

1.1 Purpose

The following document defines the use of the Platinum Series Serial Communications Protocol.

1.2 Definition of Terms and Acronyms

Sensor Element	One of the physical sensing elements on a Smart Output
AC	Alternating Current
DC	Direct Current
CS	Chip Select
ADC	Analog to Digital Converter
DAC	Digital to Analog Converter
RS485	Electrical signals used for serial communications
RS232	Electrical signals used for serial communications
CSV	Comma Separated Values
COTS	Commercially-Off-The-Shelf
ESD	Electro Static Discharge
FW	Firmware
HW	Hardware
I/O	Input/Output
LED	Light Emitting Diode
Hexadecimal	Values expressed using base 16 (2^4)

1.3 Applicable Documents

Doc. #	Name / Description	Rev. #
	Omega Engineering Coding Standard	Rev 1.2.0

2 Hardware

2.1 *Communications Interfaces*

The Platinum Series Protocol is designed to be an updated version of the original iSeries protocol which can be used over serial connections using RS-232, RS-485, USB and serial over Ethernet.

2.1.1 RS-232

This is for point to point connections at baud rates up to 115,200.

Hardware flow control is not supported.

2.1.2 RS-485

This can be used for multi-point connections. Up to 200 individual addresses can be assigned.

2.1.3 USB Virtual Comm

This is used for point to point connections the same as RS-232.

2.1.4 Ethernet

The serial protocol is transmitted using TCP/IP on port 2000.

3 Protocol Description

3.1 Protocol

The protocol is command/response, based on 4 command classes:

Get (G), Put (P), Read (R) and Write (W). A Get is used to read the current value resident in RAM, a Put is used to write a parameter to RAM without committing it to non-volatile memory. A Read is used to retrieve the value of a parameter stored in non-volatile memory and a write is used to commit a parameter value to non-volatile memory.

3.2 Command Structure

The overall structure of a command packet is as follows:

- A start of frame (SOF) character – usually ‘*’
- A command class (GPRW)
- A command ID – a hex number identifying the message.
- A mandatory space if there are parameters following the command ID.
- A parameter List.
- An end of frame (EOF) character – usually a carriage return.

A unit address is optional.

An address is a hex-encoded number in the range 0-199 (00 – C7 hex) between the start of frame and the command class.

For example, to get the current process value, without an address would be:

“*G110 <CR>”

In this case the command class is ‘G’, the command ID is 110 (hex) and this command takes no parameters.

If this were addressed to unit 100 (hex value 64), the command would be:

“*64G110 <CR>”

3.3 Response Format

The response format depends on whether a command echo has been selected. If selected, the address (if present), command class and command ID precede the parameters returned.

For example, if an echo is selected, the previous command would return:

“G110+32.0<CR>” (no address)

“64G110+32.0<CR>” (if the unit responding had address = 64 (hex).

If echo is not selected, in both cases, only “+32.0<CR>” would be returned.

For put (P) and Write (W) type transactions, only the command is echoed if echo is on. Thus,

“*Pxxx yyyyyy<CR>” will echo “Pxxx<CR>”.

3.4 Error Messages

In the event of an error in the message format, an error string is returned:

“Command Failed Decode 0”

4 Platinum Series Messages

4.1 Input Configuration

Input Configuration									
ID	Classes	Parameters							
0x100	GPRW	STYPE	SI1	SI2					

The parameters are as follows:

STYPE - Sensor Type	
Value	Type
0	Thermocouple
1	RTD
2	Process Input
3	Thermistor
4	Remote

The meaning of the two sensor info fields, SI1 and SI2 depends on the sensor type indicated in the STYPE field.

For thermocouple type (STYPE = 0)

SI1 – Sensor Info 1 Thermocouple Type)	
Value	Type
0	J
1	K
2	T
3	E
4	N
5	Reserved
6	R

7	S
8	B
9	C
10	Reserved
11	Reserved

For thermocouple, the SI2 field is irrelevant.

Example: to set input type to Type K thermocouple: “*W100 010<CR>”

For RTD Sensor type (STYPE = 1)

SI1 – Sensor Info 1 RTD Configuration	
Value	Type
0	2 Wire
1	3 Wire
2	4 Wire

SI2 – Sensor Info 1 RTD ACRV Ohm Types	
Value	Type
0	385 Curve, 100 ohms
1	385 Curve, 500 ohms
2	385 Curve, 1000 ohms
3	392 Curve, 100 ohms
4	3916Curve, 100 ohms

For Process Input (STYPE = 2)

SI1 – Process Range	
Value	Range
0	4 – 20 mA
1	0 – 24 mA
2	*NS
3	*NS
2	*NS
5	+/- 10 Vdc
6	+/- 1.0 Vdc
7	+/- 0.1 Vdc

*NS – Not currently supported.

SI2 – Sensor Info 2 Process Manual/Live	
0	Live
1	Manual

For Thermistor Type (STYPE = 3)

SE1 – Sensor Info 1 - Thermistor Type	
0	2.25 K
1	5K
2	10K

The Sensor Info 2 Field is irrelevant when STYPE = 3

For Remote Sensor Type (STYPE = 4)

This is not currently supported and is for future expansion.

4.2 Filter Constant

Filter Constant									
ID	Classes	Parameters							
0x101	GPRW	FC							

The parameters are as follows:

FC	
Value	Effect
0	No filtering (1 X rate)
1	X 2 filtering
2	X 4 filtering
3	X 8 filtering
4	X 16 filtering
5	X 32 filtering
6	X 64 filtering
7	X 128 filtering

Example: To set input filter to x2 “*W101 1<CR>”

4.3 Current Reading

Current Reading									
ID	Classes	Parameters							
0x110	G								

This does not take any parameters.

Example: To get current process reading: “*G110<CR>”

4.4 Peak Reading

Peak Reading									
ID	Classes	Parameters							
0x111	G								

This command does not take any parameters.

4.5 Valley Reading

Valley Reading									
ID	Classes	Parameters							
0x112	G								

This command does not take any parameters.

4.6 TC Calibration Type

TC Calibration Type									
ID	Classes	Parameters							
0x120	GPRW	Mode							

The parameters are as follows:

Mode	
Value	Effect
0	No Calibration
1	1 Point
2	2 Point
3	Ice Point

4.7 TC Calibration Single Point

TC Calibration Single Point		
ID	Classes	Parameters
0x121	GPRW	Value (float)

4.8 TC Calibration Double Point Low

TC Calibration Double Point Low		
ID	Classes	Parameters
0x122	GPRW	Value (float)

4.9 TC Calibration Double Point High

TC Calibration Double Point High		
ID	Classes	Parameters
0x123	GPRW	Value (float)

4.10 Process Reading 1 (Low)

Process Reading 1 (Low)				
ID	Classes	Parameters		
0x130	GPRW	PR	ML	Value (float)

PR – Process Range	
Value	Range
0	4 – 20 mA

1	0 – 24 mA
2	*NS
3	*NS
4	*NS
5	+/- 10 Vdc
6	+/- 1.0 Vdc
7	+/- 0.1 Vdc

ML – Manual/Live	
Value	Range
0	Manual Mode
1	Live Mode

*NS – not currently supported.

4.11 Process Range Input 1 (Low)

Process Range Input - Low				
ID	Classes	Parameters		
0x131	GPRW	PR	ML	Value (float)

The parameters PR and ML, are the same as defined for command ID = 0x130.

4.12 Process Range Reading 2 (High)

Process Range Reading (High)				
ID	Classes	Parameters		
0x132	GPRW	PR	ML	Value (float)

The parameters PR and ML, are the same as defined for command ID = 0x130.

4.13 Process Range Input 2 (High)

Process Range Input - High				
ID	Classes	Parameters		
0x133	GPRW	PR	ML	Value (float)

The parameters PR and ML, are the same as defined for command ID = 0x130.

4.14 Display Configuration

Display Configuration									
ID	Classes	Parameters							
0x200	GPRW	DP	UNIT	COLOR	BRT				

The parameters are as follows:

DP - Decimal Point	
Value	Effect
0	Display as F.FFF
1	Display as FF.FF

Units	
Value	Effect
0	No units applied
1	Values converted to oC
2	Values converted to oF

Color	
Value	Effect
1	GREEN
2	RED
3	AMBER

BRT - Brightness	
Value	Brightness
0	LOW
1	MEDIUM
2	HIGH

4.15 Excitation Voltage

Excitation Voltage									
ID	Classes	Parameters							
0x210	GPRW	EV							

The parameters are as follows:

EV – Excitation Voltage

Value	Voltage
0	0 Volts
1	5 Volts
2	10 Volts
3	12 Volts
4	24 Volts

4.16 Safety Configuration

Safety Configuration									
ID	Classes	Parameters							
0x220	GPRW	POR	OR	LBE					

The parameters are as follows:

POR – Power On Run	
Value	Voltage
0	Go to standby when powered on
1	Go to run when powered on

OR – Operate Run	
Value	Voltage
0	Disabled
1	Enabled

LBE - Loop Break Enabled	
Value	Enabled/Disabled

0	Disabled
1	Enabled

4.17 Loop Break Configuration

Loop Break Configuration									
ID	Classes	Parameters							
0x221	GPRW	LBE	MINMS	MINLS	SECMS	SECLS			

LBE - Loop Break Enabled	
Value	Enabled/Disabled
0	Disabled
1	Enabled

The parameters MINMS, MINLS define the minutes in the loop break time. MINMS is the most significant part of the minutes, MINLS the least significant. Both are in hex format.

For example, to encode 100 minutes, MINMS = 6, MINLS = 4. (64 hex).

The second's portion of the loop break time is similarly defined in SECMS, SECLS.

4.18 Set Point Low Limit

Set Point Low Limit		
ID	Classes	Parameters
0x222	GPRW	Value (float)

4.19 Set Point High Limit

Set Point High Limit		
ID	Classes	Parameters

0x223	GPRW	Value (float)
-------	------	---------------

4.20 Serial Communication Address

Serial Communications Address									
ID	Classes	Parameters							
0x300	GPRW	AMS	ALS						

The parameters are as follows:

AMS and ALS are the most significant and least significant nibble of the serial communications address in hex format. The address must be in the range 0 to 199 (decimal).

For example, if an address of 100 (decimal) is to be used, the hex value of the address would be 0x64 so AMS would be '6' and ALS would be '4'.

4.21 USB Communication Address

USB Communications Address									
ID	Classes	Parameters							
0x301	GPRW	AMS	ALS						

The format and parameter usage is the same as for the serial communications address.

4.22 Ethernet Communication Address

Ethernet Communications Address									
ID	Classes	Parameters							
0x302	GPRW	AMS	ALS						

The format and parameter usage is the same as for the serial communications address.

4.23 Serial Communication Config

Serial Communications Configuration									
ID	Classes	Parameters							
0x310	GPRW	PROT	DM	LFE	ECHO	SEP			

The parameters are as follows:

PROT- Protocol	
Value	Protocol
0	Omega Protocol
1	Modbus Protocol

Data Mode – Data Mode	
Value	Voltage
0	Command
1	Continuous

LFE – Line Feed Enabled	
Value	Voltage
0	Don't insert line feed on responses
1	Insert line feed

ECHO – Response Echo Enabled	
Value	Voltage
0	No echo.

1	Echo command in response
---	--------------------------

SEP - Separation Character (Omega Protocol)	
Value	Effect
0	Use <space> character between records
1	Use <CR> between records

The Serial Communications Configuration must be set before the Serial Data Mode (ID = 0x311)

4.24 Serial Data Mode Config

Serial Communications Data Mode Config			
ID	Classes	Parameters	
0x311	GPRW	MODE	Interval - seconds (variable length - float)

MODE – (Omega Protocol)	
0	Interactive command mode
1	Continuous mode

Serial Modbus Mode Config

The interval is specified as a floating point number in seconds when the continuous mode is specified.

Example: setting serial to continuous mode with 5 second interval:

“*P311 1 5.0<CR>”

4.25 Serial Modbus Mode

Serial Modbus Mode		
ID	Classes	Parameters

0x314	GPRW	MODE	
-------	------	------	--

MODE - Modbus	
Value	Mode
0	RTU
1	ASCII

4.26 Serial Data Format

Serial Data Format									
ID	Classes	Parameters							
0x312	GPRW	AS	RE	PE	VE	UE			

AS – Alarm Status Enabled in Continuous Mode	
Value	Voltage
0	Don't send alarm status in cont. mode
1	Send alarm status

RE – Readings Enabled in Continuous Mode	
Value	Voltage
0	Don't send readings in cont. mode
1	Send readings

PE – Peak Readings Enabled in Continuous Mode	
Value	Voltage
0	Don't send peak readings in cont. mode
1	Send peak readings

VE – Valley Readings Enabled in Continuous Mode	
Value	Voltage
0	Don't send valley readings in cont. mode
1	Send valley readings

UE – Valley Readings Enabled in Continuous Mode	
Value	Voltage
0	Don't append measurement units in cont. mode
1	Append measurement units in cont. mode.

4.27 Serial Communications Parameters

Serial Communications Parameters									
ID	Classes	Parameters							
0x313	GPRW	MODE	BR	PAR	DB	SB			

MODE - Serial Mode	
Value	Mode
0	RS232
1	RS485

BR - Serial Baud Rate	
Value	Rate
0	300 Baud
1	600 Baud
2	1200 Baud

3	2400 Baud
4	4800 Baud
5	9600 Baud
6	19200 Baud
7	38400 Baud
8	57600 Baud
9	115200 Baud

PAR - Parity	
Value	Parity
0	None
1	Odd
2	Even

DB - Data Bits	
Value	Bits
0	7
1	8

SB - Stop Bits	
Value	Bits
0	1
1	2

4.28 USB Communications Configuration

USB Communications Configuration									
ID	Classes	Parameters							
0x320	GPRW	PROT	DM	LFE	ECHO	SEP			

This is for use with a virtual com serial port. The usage of the parameters is the same as for the Serial Communications Message.

4.29 USB Data Mode Configuration

USB Communications Data Mode Config			
ID	Classes	Parameters	
0x321	GPRW	MODE	Interval - seconds (float)

The usage of the parameters for this command is the same as for the Serial Communications Data Mode (ID = 0x311)

4.30 USB Modbus Mode

USB Modbus Mode			
ID	Classes	Parameters	
0x323	GPRW	MODE	

MODE - Modbus	
0	RTU
1	ASCII

4.31 USB Data Format

Serial Data Format									
ID	Classes	Parameters							
0x312	GPRW	AS	RE	PE	VE	UE			

The usage of the parameters for this command is the same as for the Serial Data Format (ID = 0x312).

4.32 Ethernet Communications Configuration

Ethernet Communications Configuration									
ID	Classes	Parameters							
0x330	GPRW	PROT	DM	LFE	ECHO	SEP			

The usage of the parameters for this command is the same as for the Serial Communications Configuration (ID = 0x310).

4.33 Ethernet Data Mode Configuration

Ethernet Communications Data Mode Config									
ID	Classes	Parameters							
0x331	GPRW	MODE	Interval - seconds (float)						

The usage of the parameters for this command is the same as for the Serial Communications Data Mode (ID = 0x311).

4.34 Ethernet Data Format

Ethernet Data Format									
ID	Classes	Parameters							
0x332	GPRW	AS	RE	PE	VE	UE			

The usage of the parameters for this command is the same as for the Serial Data Format command (ID = 0x312).

4.35 Ethernet Modbus Mode

Ethernet Modbus Mode									
ID	Classes	Parameters							

0x333	GPRW	MODE	
-------	------	------	--

MODE - Modbus	
0	RTU
1	ASCII

4.36 Setpoint 1

Setpoint 1		
ID	Classes	Parameters
0x400	GPRW	Setpoint Value - variable length (float)

4.37 Remote Setpoint Configuration

Remote Setpoint Configuration									
ID	Classes	Parameters							
0x401	GPRW	EN	PR						

EN – Enable Remote Setpoint	
Value	Action
0	Enable Remote Setpoint
1	Disable Remote Setpoint

PR - Output Process Range	
Value	Range
0	4 - 20 V
1	0 – 24 V
2	0 – 10 V

3	0 – 1 V
---	---------

4.38 Setpoint 2

Setpoint 2			
ID	Classes	Parameters	
0x410	GPRW	TYPE	Setpoint Value - variable length (float)

TYPE - Setpoint Type	
Value	Action
0	Setpoint value given as fixed constant
1	Setpoint value is deviation (+/-) Setpoint 1 value

4.39 Remote Process Range Setpoint Min

Remote Process Range Setpoint Minimum			
ID	Classes	Parameters	
0x420	GPRW	PR	Setpoint Value (float – variable length)

The parameters are as follows:

PR - Output Process Range

Value	Range
0	4 - 20 V
1	0 – 24 V
2	0 – 10 V
3	0 – 1 V

4.40 Remote Process Range Setpoint Max

Remote Process Range Setpoint Maximum			
ID	Classes	Parameters	
0x422	GPRW	PR	Setpoint Value (float – variable length)

The process range parameter PR is as defined for the Remote Process Range Setpoint Min command (ID = 0x420).

4.41 Remote Process Range Input Max

Remote Process Range Input Maximum			
ID	Classes	Parameters	
0x423	GPRW	PR	Setpoint Value (float – variable length)

The process range parameter PR is as defined for the Remote Process Range Setpoint Min command (ID = 0x420).

4.42 Remote Process Range Input Min

Remote Process Range Input Minimum			
ID	Classes	Parameters	
0x421	GPRW	PR	Setpoint Value (float – variable length)

The process range parameter PR is as defined for the Remote Process Range Setpoint Min command (ID = 0x420).

4.43 PID Configuration

PID Configuration									
ID	Classes	Parameters							
0x500	GPRW	CA	AC						

CA - Control Action	
Value	Action
0	Output active if P.V. < Setpoint
1	Output active if P.V. > Setpoint

AC – Adaptive Control	
Value	Action
0	Enable Adaptive Control
1	Disable Adaptive Control

4.44 PID Low Clamping Limit

PID Low Clamping Limit									
ID	Classes	Parameters							
0x501	GPRW	CLMS	CLLS						

The hex-encoded byte fields CLMS, CLLS form the hex representation of the limit (percent) 0-100
For example, if the limit were to be 35 (decimal) the hex representation would be 23, so CLMS would equal 2 and CLLS 3.

4.45 PID High Clamping Limit

PID High Clamping Limit									
ID	Classes	Parameters							
0x502	GPRW	CLMS	CLLS						

The encoding of the high clamping limit is the same as for the low clamping limit.

4.46 PID P Parameter

PID P-Parameter		
ID	Classes	Parameters
0x503	GPRW	P-parameter Value (float – variable length)

4.47 PID I Parameter

PID I-Parameter		
ID	Classes	Parameters
0x504	GPRW	I-parameter Value (float – variable length)

4.48 PID D Parameter

PID D-Parameter		
ID	Classes	Parameters
0x505	GPRW	D-parameter Value (float – variable length)

4.49 Output Mode

Output Mode									
ID	Classes	Parameters							
0x600	GPRW	NOUT	MODE						

NOUT – the output number (1-4)

MODE - Output Mode	
Value	Mode
0	Output maintained in OFF state
1	Output control by PID control function
2	Output controlled by ON-OFF control function
3	Output retransmits the scaled process variable
4	Output set by ALARM 1 state
5	Output set by ALARM 2 state
6	Output set by Ramp & Soak RE.ON control bit
7	Output set by Ramp & Soak SE.ON control bit

4.50 Output Type

Output Type									
ID	Classes	Parameters							
0x601	G	NOUT							

NOUT – the output number

This returns the output type for the specified output as a hex encoded string as follows:

Output Types	
Code Returned (hex encoded)	Type
000	No output available
001	Single Poll Relay
002	SSR output
004	Double Poll Relay
008	DC Pulse output
010	Analog Output
020	Isolated Analog Output

4.51 Output ON/OFF Configuration

Output On/Off Config				
ID	Classes	Parameters		
0x610	GPRW	NOUT	RD	Dead Band Value (float – variable length)

NOUT is the output number (1-4)

RD – Reverse/Direct	
Value	Action
0	Reverse
1	Direct

4.52 Output Alarm Configuration

Output Alarm Configuration		
ID	Classes	Parameters

0x620	G	NAL	TYP	MODE	COLOR	HHEN	LAT	CNT	PO
-------	---	-----	-----	------	-------	------	-----	-----	----

NAL is the alarm number (1-2)

TYP- Alarm Type	
0	Alarm not active
1	Alarm triggered if PV > ALM.H
2	Alarm trigger if PV < ALM.L
3	Alarm trigger if PV > ALM.H or PV < ALM.L
4	Alarm trigger if PV > ALM.L and PV < ALM.H

MODE - Alarm Mode	
Value	Mode
0	Alarm setpoint is fixed constant
1	Alarm is offset from Setpoint 1
2	Alarm is offset from Setpoint 2

Color	
Value	Alarm Color
0	No color
1	GREEN
2	RED
3	AMBER

HHEN – HiHi Mode	
Value	Action
0	Enable Hi Hi Mode
1	Disable Hi Hi Mode

LAT- Alarm Latch Control	
Value	Action
0	Alarm does not latch
1	Alarm state will be latched, clear by front panel
2	Alarm state will be latched, clear by digital input
3	Alarm state latched, clear by front panel or input

CNT – Contact Polarity	
Value	Polarity
0	Contacts OPEN until activated
1	Contacts CLOSED until activated

PO – Power On Enable	
0	Not active on power-on
1	Active on power-on

4.53 Hi Value

Alarm Hi Value			
ID	Classes	Parameters	
0x621	GPRW	NAL	Hi Value (float – variable length)

NAL = alarm number (1-2)

4.54 Low Value

Alarm Low Value			
ID	Classes	Parameters	
0x622	GPRW	NAL	Low Value (float – variable length)

4.55 On Delay

Alarm On Delay			
ID	Classes	Parameters	
0x623	GPRW	NAL	On Delay - seconds (float – variable length)

NAL = alarm number (1 – 2)

4.56 Off Delay

Alarm Off Delay			
ID	Classes	Parameters	
0x624	GPRW	NAL	Off Delay - seconds (float – variable length)

NAL – alarm number (1-2)

4.57 HiHi Mode

HiHi Mode									
ID	Classes	Parameters							
0x625	GPRW	NAL	ON/OFF						

NAL – alarm number

ON/OFF	
0	On
1	Off

4.58 HiHi Offset

Alarm HiHi Offset			
ID	Classes	Parameters	
0x626	GPRW	NAL	Offset (float – variable length)

4.59 Output Retransmission Reading 1

Output Retransmission Reading 1			
ID	Classes	Parameters	
0x630	GPRW	NOUT	Reading Value (float – variable length)

NOUT – output number (1-4)

4.60 Output Retransmission Output 1

Output Retransmission Output 1			
ID	Classes	Parameters	
0x631	GPRW	NOUT	Output Value (float – variable length)

NOUT – output number (1-4)

4.61 Output Retransmission Reading 2

Output Retransmission Reading 2			
ID	Classes	Parameters	
0x632	GPRW	NOUT	Reading Value (float – variable length)

NOUT = output number (1-4)

4.62 Output Retransmission Output 2

Output Retransmission Output 2			
ID	Classes	Parameters	
0x633	GPRW	NOUT	Output Value (float – variable length)

NOUT – output number (1-4)

4.63 Output Cycle Time/Pulse Width

Output Cycle Time/Pulse Width			
ID	Classes	Parameters	
0x650	GPRW	NOUT	Cycle Time - seconds (float – variable length)

NOUT – output number

4.64 Output Range

Output Range									
ID	Classes	Parameters							
0x660	GPRW	NOUT	RANGE						

RANGE	
Value	Range
0	0 – 10V
1	0 – 5V
2	0-20V
3	4-20V
4	0-24V

4.65 Time Format

Time Format									
ID	Classes	Parameters							
0x700	GPRW	FMT							

FMT - Time Format	
0	MM.SS displayed
1	HH.MM displayed
2	S.MMM displayed

4.66 Multi Ramp/Soak Configuration

Ramp/Soak Config									
ID	Classes	Parameters							
0x720	GPRW	RS							

RS – Ramp Soak Mode	
0	Ramp/Soak Disabled
1	Ramp/Soak Enabled
2	Ramp/Soak Remote Control

4.67 Multi Ramp/Soak Profile Configuration

Multi Ramp/Soak Profile Config									
ID	Classes	Parameters							
0x721	RW	PMS	PLS	SC	TE				

PMS, PLS form the profile number in hex form. PMS is the most significant hex digit, PLS the least significant. For example, segment 31 (0x1f) would be encoded as PMS = '1', PLS = 'F'

SC is the segment count (0 – 15) encoded as a single hex digit.

TE- Tracking Enabled	
0	Disabled
1	Enabled

4.68 Multi Ramp/Soak Segment Event Configuration

Multi Ramp/Soak Event Config									
ID	Classes	Parameters							
0x730	RW	NSEG	RE	SE					

PMS, PLS identify the profile number as in Multi Ramp/Soak Profile Configuration (ID = 0x721).

NSEG is the segment number encoded as a single hex digit (0-F)

RE – Ramp enabled (1) or disabled (0) for segment

SE – Soak enabled (1) or disabled (0) for segment.

4.69 Multi Ramp/Soak Profile Segment Ramp Time

Multi Ramp/Soak Segment Ramp Time			
ID	Classes	Parameters	
0x731	RW	NSEG	Ramp Time Seconds (float, variable length)

NSEG is a single hex digit identifying the segment number

4.70 Multi Ramp/Soak Profile Segment Soak Process Value

Multi Ramp/Soak Segment Soak Process Value
--

ID	Classes	Parameters	
0x732	RW	NSEG	Soak Value (float, variable length)

NSEG is a single hex digit identifying the segment number

4.71 Multi Ramp/Soak Profile Segment Soak Time

Multi Ramp/Soak Segment Soak Time			
ID	Classes	Parameters	
0x733	RW	NSEG	Soak Time - seconds (float, variable length)

PMS, PLS pair identify the profile number as in the Multi-Ramp Profile Config message (ID = 0x721)

NSEG is a single hex digit identifying the segment number

4.72 INIT Password

INIT Password									
ID	Classes	Parameters							
0xF00	GPRW	EN	PWD3	PWD2	PWD1	PWD0			

EN – Enable Init (1) / Disable Init (0)

The parameters PWD0-3 form a hex encoded number. The range of each must be 0-9. For example, '1234' would be encoded as PWD3 = 1, PWD2 = 2, PWD1 = 3, PWD0 = 4

4.73 Program Password

Program Password									
ID	Classes	Parameters							
0xF01	GPRW	EN	PWD3	PWD2	PWD1	PWD0			

EN – Enable Programming (1) / Disable Programming (0)

The parameters PWD0-3 form a hex encoded number. The range of each must be 0-9.

4.74 Version Number

Version Number									
ID	Classes	Parameters							
0xF20	G								

This command returns the current firmware version number as a hex encoded string. The format is:

- Major (2 bytes)
- Minor (2 bytes)
- Fix (2 bytes)
- Build (2 bytes)

Example: If the current version is 01.00.05.00 the command “*GF20<CR>” would return “01000500”

4.75 Version Upgrade

Version Upgrade									
ID	Classes	Parameters							
0xF21	P	SEL							

This command forces a firmware upgrade, followed by a reboot.

The SEL parameter determines the method to be used.

SEL – Firmware Upgrade Method	
1	EIP Serial Port
2	User Serial Port
3	USB Thumb drive.

Example: to upgrade using the USB Thumb drive the drive would be inserted into the USB port, followed by the serial command “*PF21 3<CR>”

4.76 Bootloader Version

Bootloader Version Number									
ID	Classes	Parameters							
0xF22	G								

This retrieves the bootloader version number in exactly the same manner as the version number command (ID = 0xF20).

4.77 Set Factory Defaults

Bootloader Version Number									
ID	Classes	Parameters							
0xF30	P	EN							

To reset factory defaults, use the command “*PF30 1<CR>”

Warranty/Disclaimer

NEWPORT Electronics, Inc. warrants this unit to be free of defects in materials and workmanship for a period of **one (1) year** from the date of purchase. In addition to NEWPORT's standard warranty period, NEWPORT Electronics will extend the warranty period for **four (4) additional years** if the warranty card enclosed with each instrument is returned to NEWPORT.

If the unit should malfunction, it must be returned to the factory for evaluation. NEWPORT's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by NEWPORT, if the unit is found to be defective it will be repaired or replaced at no charge. NEWPORT's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of NEWPORT's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

NEWPORT is pleased to offer suggestions on the use of its various products. However, NEWPORT neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by NEWPORT, either verbal or written. NEWPORT warrants only that the parts manufactured by it will be as specified and free of defects. NEWPORT MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of NEWPORT with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall NEWPORT be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by NEWPORT is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, or used on humans, or misused in any way, NEWPORT assumes no responsibility as set forth in our basic WARRANTY / DISCLAIMER language, and additionally purchaser will indemnify NEWPORT and hold NEWPORT harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

Return Requests/Inquiries

Direct all warranty and repair requests/inquiries to the NEWPORT Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO NEWPORT, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM NEWPORT'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting NEWPORT:

1. P.O. number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult NEWPORT for current repair charges. Have the following information available BEFORE contacting NEWPORT:

1. P.O. number to cover the COST of the repair,
2. Model and serial number of product, and
3. Repair instructions and/or specific problems relative to the product.

NEWPORT's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

NEWPORT is a registered trademark of NEWPORT Electronics, Inc. Patent pending.

© Copyright 2015 NEWPORT Electronics, Inc. All rights reserved. This document may not be copied, photo-copied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of NEWPORT Electronics, Inc.



1-800-6397678[®]
1-800-NEWPORT

Newport Electronics, Inc.
2229 South Yale Street • Santa Ana, CA • 92704 • U.S.A.
TEL: (714) 540-4914 • FAX: (203) 968-7311
Toll Free: 1-800-639-7678 • www.newportUS.com • e-mail: info@newportUS.com
ISO 9001 Certified

Newport Technologies, Inc.
976 Bergar • Laval (Quebec) • H7L 5A1 • Canada
TEL: (514) 335-3183 • FAX: (514) 856-6886
Toll Free: 1-800-639-7678 • www.newport.ca • e-mail: info@newport.ca

Newport Electronics, Ltd.
One Omega Drive • River Bend Technology Centre
Northbank, Irlam • Manchester M44 5BD • United Kingdom
Tel: +44 161 777 6611 • FAX: +44 161 777 6622
Toll Free: 0800 488 488 • www.newportuk.co.uk • e-mail: sales@newportuk.co.uk

Newport Electronics B.V. - Benelux
Managed by the United Kingdom Office
TEL: +31 20 3472121 • FAX: +31 20 6434643
Toll Free: 0800 0993344 • www.newport.nl • e-mail: info@newport.nl

Newport Electronics spol s.r.o.
Frystatska 184, 733 01 Karviná • Czech Republic
TEL: +420 59 6311899 • FAX: +420 59 6311114
Toll Free: 0800-1-66342 • www.newport.cz • e-mail: info@newport.cz

Newport Electronics GmbH
Daimlerstrasse 26 • D-75392 Deckenpfronn • Germany
TEL: 49 7056 9398-0 • FAX: 49 7056 9398-29
Toll Free: 0800 / 6397678 • www.newport.de • e-mail: sales@newport.de

Newport Electronique S.A.R.L. - France
Managed by the United Kingdom Office
TEL: 01 57 32 48 17 • FAX: 01 57 32 48 18
Toll Free: 0805 541 038 • www.newport.fr • e-mail: sales@newport.fr

Mexico and Latin America
FAX: 001 (203) 359-7807
TEL En Español: 001 (203) 359-7803

NEWPORTnetSM On-Line Service www.newportUS.com	Internet e-mail info@newportUS.com
--	--